

Exhibitor Products (Straight Flat Walls™)

Applicable Products:

FW088

FW108

1. Connect upright sections together. Shortest upright section should go on top (fig. A).
2. Slide corner bracket over upright until push button clicks into place (fig. B).
3. Slide upright over base upright until push button clicks into place (fig. C).
4. Press bottom crossbar sections in between uprights until push buttons click into place. Short crossbar section with two push buttons should be placed on the left (fig. D).
5. Press top crossbar sections in between uprights until push buttons click into place. Short crossbar section with two push buttons should be placed on the left (fig. E).
6. Slide pillowcase graphic over frame and zipper at bottom to complete unit assembly (not shown).

NOTE: Model shown below may differ from your model. While the number of crossbar and upright sections may differ depending on the model, assembly instructions remain the same.

