

How to use Banner Clips
(For flags/banners without grommets - indoor or outdoor use)



Flip the clip so the bottom side is facing you



Push the middle "teeth" down and gently pull the clip apart



Flip the clip so the top is facing you and place the extended portion on the desired locations underside.



Push the top portion of the clip down and over the material until the "teeth" have clicked enough to hold in place.

For more how-to's and flag etiquette, visit <https://www.flagandbanner.com/faq>