



TAURUS BANNER STAND ASSEMBLY INSTRUCTIONS

Product Parts

- 1 - Hub and Bottom Legs
- 2 - Arms



Step 1

Remove all parts from the bag. Place the unit on the ground/work surface

Step 2

Press the center button on the Hub (1) to move the Bottom Legs (1). Spread the front Bottom Legs to approximately the width of your banner. Lay the unit face up on the floor.



Step 3

Slip each Arm (2) into the holes on the top of the Hub (1), being sure that the hooks face the same direction as those on the Bottom Legs (1).



Step 4

Lay the banner flat, printed side up, on top of the banner stand. Slip the grommets onto the hooks on each corner. The Stand will need to bend, which will pull the banner taut. Stand the unit upright, and rotate the back leg out support the stand.

Gently bend Arms (2) when attaching banner.

Caution: Do not force a smaller than recommended banner on the display as it may cause damage to the unit.

